Model No: HJ-ME17T

JVC

HJ-ME17T

QUICK START GUIDE

Please read this Quick Start Guide carefully and keep it for future use.

Charging

Before using the " **HJ-ME17T** " , please connect the USB-C cable to a power adapter to begin charging. Fully charge the earphones and the charging case before the first use.



USB-C Port

Power On/Off

Open the charging case cover, take out the earphones. The earphones will automatically turn on. If you want to turn off the earphones, please put them back into the charging case. The earphones will shut down and start charging at the same time.

Pairing

Open the charging case cover, take out the earphones. The earphones will automatically turn on. For new device connection, turn on the bluetooth in your device and choose " **HJ-ME17T** " from the Bluetooth list to connect. You will hear system prompts after the earphones are connected to the device. If the earphones have been connected before, they will connect to the last connected device automatically after being turned on.

Wearing

Put the " **HJ-ME17T** " onto your ears and rotate to fit comfortably to get the best wearing and sound quality experience.



MFB Operation

Reset

In the power on state, press the MFB of the earphones 5 times (two earphones at the same time), and the earphones will automatically shut down to reset. Put the earphones in the charging case and then take them out, the earphones will turn on automatically, and enter the pairing mode.

Additional Operation

Answer call	Press L or R twice
End call	Press L or R twice
Reject call	Press MFB on the left or right earphone for 2 seconds
LED indicator (earphone)	
Power on	White flashes
Power off	The white light on 2s and then turn off
Pairing is successful	The white light on 1s and then turn off
Pairing timed out	The white light on 2s and then turn off
Disconnect the phone	White flashes
Low battery	white flashing slowly
Charging	The white lights remain on, and then they all go out
LED indicator (charging case)	
Charging	When the battery level drops below 20%, charging begins. The orange light remains on continuously. When the battery level reaches 30% or above, the light turns to a white continuous glow. Once fully charged, the light goes out. When the battery level is above 20%, charging begins. The white light remains on continuously until the battery is fully charged and then turns off.
Discharge	When the charging dock charges the headphones, the white light stays on continuously until the charge is complete and then it goes out

Product Cleaning

We recommend regularly cleaning the charging contacts of the charging case and the earbuds, as well as their surfaces.



Attention

•Private replacement of batteries without permission is not recommended.
•Batteries [battery packs or battery combinations] should not be exposed to lighting, baking or similar overheating environments.
•The input voltage and current standard ≤ 5V/0.5A when charging the headset charging compartment from an external power source;

The model approval code (CMIIT ID) of the radio transmission equipment of this device has been printed on the product body in silk screen.

JVC is a trademark of JVCKENWOOD Corporation, used by Shenzhen Monster Creative Technology Co., Ltd. under license.

This product is exclusively developed, manufactured, marketed, and serviced by Shenzhen Monster Smart Internet Co., Ltd. (Shenzhen Monster Creative Technology Co., Ltd.).

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Shenzhen Monster Creative Technology Co.,Ltd is under license. Other trademarks and trade names are those of their respective owners.

⚠ Safety Warnings and Precautions

To ensure your safety and extend the service life of this product, please strictly follow the warnings below:
1. Environmental Warnings
• Do not use this product in extremely high or low temperatures, or in dusty or humid environments.
• Avoid direct sunlight, fire exposure, or any overheating conditions.
• In environments with strong wireless signals or dense crowds (such as airports, stations, exhibitions, etc.), intermittent connection or interference may occur. This is within normal range. Please continue to use the device later or change the usage environment.
2. Operational Safety Warnings
• Do not drop, strike, or subject the product to strong vibrations.
• Do not disassemble or modify the device without authorization to avoid hazards or damage.
• If any abnormal condition occurs, stop using the product immediately and contact your distributor.
3. Battery and Charging Warnings
• When the charging case indicator shows low battery, please recharge in time. If the product is not used for a long period, please recharge it at least once every 30 days.
• Use power adapters that comply with national standards and are CCC-certified.
• The earbuds contain built-in batteries. Do not expose them to high temperatures or flammable environments.
• If the charging port of the earbuds contains foreign objects or has poor contact, gently clean the charging port with a cotton swab dipped in alcohol. Regular cleaning is recommended to ensure proper charging and power-on/off functions.
4. Important Notes
• If there are updates or changes to product functions, please refer to the official website or the sales page for the latest information.
• Please keep this manual for future reference.

Model No: HJ-ME17T

JVC

HJ-ME17T

快速指南

请仔细阅读快速指南并妥善保存以备将来使用
本产品由中国平安保险公司承保

充电

请在使用此设备前先给耳机和充电仓充满电，此设备可以通过USB-C 接口进行充电。



USB-C 接口处

电源开、关

打开充电盒盖，拿出耳机，耳机将自动开机。如果想要关闭耳机，请将耳机放入充电盒，耳机会关机同时进行充电。

配对

打开充电盒盖，拿出耳机，耳机将自动开机。对于新设备连接，请打开蓝牙设备并搜索 " **HJ-ME17T** " 进行连接，配对成功后，您会听到系统提示音。如果耳机之前已配对过，开机就会尝试连接上一次的设备。

佩戴

拿出耳机，将 " **HJ-ME17T** " 放入耳中，并轻轻旋转至舒适位置，以确保获得最佳的佩戴效果和音质体验。



按键操作

恢复出厂设置

开机状态下连续5击耳机触控键（双耳同时），耳机将自动关机，恢复出厂设置。耳机放入充电盒再取出，耳机重新开机，进入配对模式。

更多操作

接听	双击左或右耳
挂断	双击左或右耳
拒接	长按左或右耳MFB键2S
LED 指示灯 (耳机)	
开机	白灯快闪
关机	白灯长亮2s熄灭
配对成功	白灯长亮1s熄灭
配对超时	白灯长亮2s熄灭
断开手机连接	白灯快闪
低电提醒	白灯慢闪
故电	充电时白灯长亮，充满白灯熄灭
LED 指示灯 (充电盒)	
充电	充电仓低于20%电量时充电，橙灯长亮。 充至30%或以上至为白灯长亮，充满熄灭
	充电仓高于20%电量时充电，白灯长亮。 充满熄灭
故电	充电仓给耳机充电时白灯长亮，充满熄灭

产品清洁

建议定期清理充电盒充电触点和耳机充电触点及表面。



注意

*不建议未经许可私下更换电池。
*电池(电池组或电池组合)不得暴露在照明,烘烤或类似过热的环境中。
*耳机充电仓在外接电源充电时，输入电压电流标准≤ 5V/0.5A;

本设备的无线电发射设备型号核准代码 (CMIIT ID) 已印制在产品本体丝印上。

" JVC " 是JVCKENWOOD株式会社的注册商标，由该公司授权深圳市魔声创新技术有限公司使用。
本产品由深圳市怪兽智能互联网有限公司(深圳市魔声创新技术有限公司)独家研发、制造、营销与服务。

" Bluetooth® " 这一标识及相关标志均为蓝牙技术联盟公司 (Bluetooth SIG, Inc.) 的注册商标，Shenzhen Monster Creative Technology Co.,Ltd 对这些标识的使用均需获得授权许可，其他商标及商号均为其各自所有者的财产。



⚠ 安全警示与注意事项

为确保您的安全并延长产品使用寿命，请严格遵守以下警示内容：
一、使用环境警告
• 禁止在极端高温、低温、多尘或潮湿环境中使用本产品。
• 避免阳光直射、火烤或任何过热环境。
• 在强无线信号或人群密集的环境（如机场、车站、展会等），可能出现耳机连接断续或干扰现象，正常范围，请稍后继续使用或更换使用环境。
二、操作安全警告
• 请勿摔落、撞击或剧烈震动产品。
• 禁止擅自拆卸或改装本机，以免造成危险或损坏。
• 若出现异常情况，请立即停止使用并联系经销商。
三、电池与充电警示
• 当充电仓指示灯提示电量低时，请及时充电。产品闲置未长期使用时，请每30天内充电一次。
• 使用符合国家标准并获得CCC认证的电源适配器。
• 耳机含内置电池，请勿置于高温或可燃环境中。
• 当耳机充电接口有异物且接触不良时，请用棉签沾酒精轻轻擦拭清洁耳机充电接口。要保持定期清洁耳机充电口，以保证正常充电与开关机的功能。
四、重要提示
• 产品功能如有变更，如未及时通知，请关注产品官网或销售链接；
• 请妥善保管本说明书以备查阅。

保修信息卡

信息填写

产品名称：

产品型号：

产品SN号：

购机日期：

用户信息

用户姓名：

联系电话：

地　址：

封面

65X90MM 105G双胶+K+4C印刷+风琴折