75X103MM 105G双胶+K+4C印刷+骑马钉

封面

Model No.: HJ-ME18T

JVC

快速指南

JVC E18T 入耳式蓝牙耳机

本产品由中国平安保险公司承保

产品介绍



LED 指示灯 (耳机) 状态:
开机: 蓝灯快闪
关机: 红灯长亮1S熄灭
配对成功: 蓝灯熄灭
配对超时: 红灯长亮1S熄灭
断开手机连接: 蓝灯快闪
低电提醒: 红灯持续呼吸慢闪
LED 指示灯 (充电盒) 状态:
充电: 充电时数显屏电量个位数字闪烁, 充电过程中显示屏电量数字会不断增加, 对应的耳机电量条从下往上跑马闪, 充满电量显示100满电后熄灭
放电: 仓放耳机充电时, 充电仓显示当前电量, 耳机对应跑马灯; 充满电后耳机红灯熄灭
低电提醒: 电量显示灯闪烁

按键操作

通话
接听/结束通话: 双击多功能触控键 (左右耳机均可操作)。
拒接来电: 三击多功能触控键 (左右耳机均可操作)。

音乐
播放/暂停: 双击多功能触控键(左右耳机均可操作)。
上一曲: 已连接手机状态,左耳机触击3下多功能触控键。
下一曲: 已连接手机状态,右耳机触击3下多功能触控键。

睡眠模式
已连接手机状态,四击左或右耳进入睡眠模式;再四击左或右耳切换到普通模式
注意:进入睡眠模式后,耳机触击功能将不可用,仅能通过四击左或右耳来切换模式

佩戴

拿出耳机, 将 " **JVC E18T** " 放入耳中, 并轻轻旋转至舒适位置, 以确保获得最佳的佩戴效果和音质体验。



配对

打开充电盒盖, 取出耳机, 耳机将自动开机。对于新设备连接, 请打开蓝牙设备并搜索 " **JVC E18T** " 进行连接, 配对成功后, 您会听到系统提示音。
如果耳机之前已配对过, 开机就会尝试连接上一次的设备。

恢复出厂设置

耳机在开机状态时, 双耳同时快击5下, 耳机自动关机入仓充电复位 (清除耳机与手机的配对记录, 不清除左右耳), 当再次取出耳机将会开机并且重新搜索配对。

产品清洁

建议定期清理充电盒充电触点和耳机充电触点及表面。

注意

*不建议未经许可私下更换电池。
*电池(电池组或电池组合)不得暴露在照明, 烘烤或类似过热的环境中。
*耳机充电仓在外接电源充电时, 输入电压电流标准≤ 5V/0.5A;

本设备的无线电发射设备型号核准代码 (CMIIT ID) 已印制在产品本体丝印上。

"JVC"是JVCKENWOOD株式会社的注册商标, 由该公司授权深圳市魔声创新技术有限公司使用。
本产品由深圳市慧鲁能互联网有限公司(深圳市魔声创新技术有限公司)独家研发, 制造, 营销与服务。

" Bluetooth® "这一标识及相关标志均为蓝牙技术联盟公司 (Bluetooth SIG, Inc.)的注册商标, Shenzhen Monster Creative Technology Co., Ltd 对这些标识的使用均需获得授权许可, 其他商标及商号均为其各自所有者的财产。

▲安全警示与注意事项

为确保您的安全并延长产品使用寿命，请严格遵守以下警示内容：

一、使用环境警告
・禁止在极端高温、低温、多尘或潮湿环境中使用本产品。
・避免将充直射、火烤或任何过热环境。
・在强无线信号或人群密集的环境（如机场、车站、展会等），可能出现耳机连接断续或干扰现象，正常范围，请稍后继续使用或更换使用环境。

二、操作安全警告
・请勿摔落、撞击或剧烈震动产品。
・禁止擅自拆卸或改装本机，以免造成危险或损坏。
・若出现异常情况，请立即停止使用并联系经销商。

三、电池与充电警示
・当充电仓指示灯提示电量低时，请及时充电。产品闲置未长期使用时，请每30天内充电一次。
・使用符合国家标准并获得3C认证的电源适配器。
・耳机含内置电池，请勿置于高温或可燃环境中。
・当耳机充电接口有异物且接触不良时，请用棉签沾酒精轻轻擦拭清洁耳机充电接口。禁保持定期清洁耳机充电口，以保证正常充电与开关机的功能。

四、重要提示
・产品功能如有变更，如未及时通知，请关注产品官网或销售链接；
・请妥善保管本说明书以备查阅。

产品合格证

保修信息卡

信息填写

产品名称:

产品型号:

产品SN号:

购机日期:

用户信息

用户姓名:

联系电话:

地　址:

Model No.: HJ-ME18T

JVC

QUICK START GUIDE

JVC E18T In-Ear Bluetooth® Headphone

Product Overview



LED indicator (earphone)
Power on: Blue flashes
Power off: The red light on 1s and then turn off
Pairing is successful: The blue light off
Pairing timed out: The red light on 1s and then turn off
Disconnect the phone: Blue flashes
Low battery: The red light is breathing slowly and flashing
LED indicator (charging case)
Charging: When charging, the digital display battery number flashes in one digit. During the charging process, the batterynumber on the display screen will continue to increase. When fully charged, the display will display 100 and then goes off.
Discharge: When charging the headphones, the charging case displays the current battery level, and the corresponding indicator light on the earphone flashes; once fully charged, the red light on the headphones goes out.
Low battery: The battery indicator light is flashing

MFB Operation

Call

Answer/end a call: Double press the MFB button (both left and right earphone can be operated).
Reject the call: Press 3 times the MFB button (both left and right earphone can be operated).

Music

Play/pause: Double press the MFB button (both left and right earphone can be operated).
Previous song: Connected mobile phone status, left earphone quickly press 3 times.
Next song: Connected mobile phone status, right earphone quickly press 3 times.

Sleep Mode

When the phone is connected, four strikes to the L or R to enter the sleep mode, four strikes to the L or R again to switch the normal mode.
Note:After entering the sleep mode, the tap function of the earphones will be unavailable. You can only switch the mode by four strikes to the L or R.

Wearing

Put the " **JVC E18T** " onto your ears and rotate to fit comfortably to get the best wearing and sound quality experience.

Pairing

Open the cover of the charging case ,take out the earphones,the earphones will turn on automatically.For new device connection, turn on the Bluetooth in your device and choose " **JVC E18T** " from the Bluetooth list to connect. You will hear system prompts after the earphones are connected to the device.
If the earphones have been connected before, they will connect to the last connected device automatically after being turned on.

Reset

In the power on state, touch the MFB of the earphones 5 times (two earphones at the same time),The earphones will automatically power off, return to the charging case, and perform a reset (this clears the pairing record between the earphones and the phone, but does not reset the left/right earphones pairing), When the earphones are taken out again, they will power on and search for a new pairing.

Product Cleaning

We recommend regularly cleaning the charging contacts of the charging case and the earbuds, as well as their surfaces.



Attention

*Private replacement of batteries without permission is not recommended.
*Batteries [battery packs or battery combinations] should not be exposed to lighting, baking or similar overheating environments.
*The input voltage and current standard ≤ 5V/0.5A when charging the headset charging compartment from an external power source;

The model approval code (CMIIT ID) of the radio transmission equipment of this device has been printed on the product body in silk screen.

JVC is a trademark of JVCKENWOOD Corporation, used by Shenzhen Monster Creative Technology Co., Ltd. under license.

This product is exclusively developed, manufactured, marketed, and serviced by Shenzhen Monster Smart Internet Co., Ltd. (Shenzhen Monster Creative Technology Co., Ltd.).

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Shenzhen Monster Creative Technology Co., Ltd is under license. Other trademarks and trade names are those of their respective owners.

▲Safety Warnings and Precautions

To ensure your safety and extend the service life of this product, please strictly follow the warnings below:
1. Environmental Warnings
• Do not use this product in extremely high or low temperatures, or in dusty or humid environments.
• Avoid direct sunlight, fire exposure, or any overheating conditions.
• In environments with strong wireless signals or dense crowds (such as airports, stations, exhibitions, etc.), intermittent connection or interference may occur. This is within normal range. Please continue to use the device later or change the usage environment.
2. Operational Safety Warnings
• Do not drop, strike, or subject the product to strong vibrations.
• Do not disassemble or modify the device without authorization to avoid hazards or damage.
• If any abnormal condition occurs, stop using the product immediately and contact your distributor.
3. Battery and Charging Warnings
• When the charging case indicator shows low battery, please recharge in time. If the product is not used for a long period, please recharge it at least once every 30 days.
• Use power adapters that comply with national standards and are LVD-certified.
• The earbuds contain built-in batteries. Do not expose them to high temperatures or flammable environments.
• If the charging port of the earbuds contains foreign objects or has poor contact, gently clean the charging port with a cotton swab dipped in alcohol. Regular cleaning is recommended to ensure proper charging and power-on/off functions.
4. Important Notes
• If there are updates or changes to product functions, please refer to the official website or the sales page for the latest information.
• Please keep this manual for future reference.

封底