75X103MM 105G双胶+K+185C印刷+骑马钉

封面

JVC

快速指南

HJ-ME28A 耳夹式蓝牙耳机

本产品由中国平安保险公司承保

产品介绍



LED 指示灯（耳机）状态：
开机：白灯长亮2秒灭
关机：白灯长亮2秒灭
配对成功：指示灯熄灭
配对超时：白灯长亮2S熄灭
断开手机连接：白蓝灯交替闪烁
低电提醒：白灯快闪
LED 指示灯（充电盒）状态：
充电：蓝灯闪烁，充满长亮
放电：仓给耳机充电时白灯长亮，充满熄灭
低电提醒：白灯快闪

按键操作

通话
接听/结束通话：双击多功能触控键（左右耳机均可操作），
拒接来电：长按2秒多功能触控键（左右耳机均可操作）。

音量控制
调低音量：在音乐播放状态下，短按左耳机的多功能触控键。
调高音量：在音乐播放状态下，短按右耳机的多功能触控键。

音乐
播放/暂停：双击多功能触控键（左右耳机均可操作）。
上一曲：已连接手机状态，左耳机轻点3下多功能触控键。
下一曲：已连接手机状态，右耳机轻点3下多功能触控键。

语音助手
已连接手机状态，长按3秒多功能触控键唤醒语音助手（左右耳机均可操作）。

佩戴
拿出耳机，将“HJ-ME28A”放入耳中，并轻轻旋转至舒适位置，以确保获得最佳的佩戴效果和音质体验。



配对
打开充电盒盖，取出耳机，耳机将自动开机。对于新设备连接，请打开蓝牙设备并搜索“HJ-ME28A”进行连接。配对成功后，您会听到系统提示音。
如果耳机之前已配对过，开机就会尝试连接上一次的设备。

恢复出厂设置
耳机在开机状态时，双耳同时快击5下，耳机自动关机入仓充电复位（请除耳机与手机的配对记录，不清除左右耳），当再次取出耳机将会开机并且重新搜索配对。

产品清洁
建议定期清理充电盒充电触点和耳机充电触点及表面。

注意
*不建议未经许可私下更换电池。
*电池(电池组或电池组合)不得暴露在阳光、烟雾或类似过热的环境中。
*耳机充电仓在外接电源充电时，输入电压电流标准≤ 5V/0.5A；

本设备的无线电发射设备型号核准代码（CMIIT ID）已印制在产品本体丝印上。

“JVC”是JVCKENWOOD株式会社的注册商标，由该公司授权深圳市魔声创新技术有限公司使用。
本产品由深圳市理音智智能互联网有限公司(深圳市魔声创新技术有限公司)独家研发、制造。

“Bluetooth®”这一标识及相关标志均为蓝牙技术联盟公司(Bluetooth SIG, Inc.)的注册商标。Shenzhen Monster Creative Technology Co., Ltd 对这些标识的使用均需获得授权许可，其他商标及商号均为其各自所有者的财产。

▲安全警示与注意事项
为确保您的安全并延长产品使用寿命，请严格遵守以下警示内容：
一、使用环境警告
・禁止在极端高温、低温、多尘或潮湿环境中使用本产品。
・避免阳光直射、火烤或任何过热环境。
・在强无线信号或人群密集的环境（如机场、车站、展会等），可能出现耳机连接断续或干扰现象，正常范围，请稍后继续使用或更换使用环境。
二、操作安全警告
・请勿摔落、撞击或剧烈震动产品。
・禁止擅自拆卸或改装本机，以免造成危险或损坏。
・若出现异常情况，请立即停止使用并联系经销商。
三、电池与充电警示
・当充电仓指示灯提示电量低时，请及时充电。产品闲置未长期使用时，请每30天内充电一次。
・使用符合国家标准并获得VD认证的电源适配器。
・耳机选内置电池，请勿置于高温或可燃环境中。
・当耳机充电接口有异物且接触不良时，请用棉签沾酒精轻轻擦拭清洁耳机充电接口。重保持定期清洁耳机充电口，以保证正常充电与开关机的功能。
四、重要提示
・产品功能如有变更，如未及时通知，请关注产品官网或销售链接；
・请妥善保管本说明书以备查阅。

有害物质	铅 (Pb)	汞 (Hg)	镉 (Cd)	六价铬 (Cr(VI))	多溴联苯 (PBB)	多溴二苯醚 (PBDE)	邻苯二甲酸二(2-乙基)己酯 (DEHP)	邻苯二甲酸丁苄酯 (BBP)	邻苯二甲酸二丁酯 (DBP)	邻苯二甲酸二异丁酯 (DIBP)
金属部件	○	○	○	○	○	○	○	○	○	○
塑料部件	○	○	○	○	○	○	○	○	○	○
线材	○	○	○	○	○	○	○	○	○	○
电路板组件	○	○	○	○	○	○	○	○	○	○

本表格依照SJ/T11364-2014的规定编制。
○:表示该有毒有害物质在该部件的均质材料中的含量均在GB/T26572规定的限量要求以下。
×:表示该有毒有害物质至少在该部件的均质材料中的含量均超出GB/T26572规定的限量要求。

保修信息卡

信息填写

产品名称：

产品型号：

产品SN号：

购机日期：

用户信息

用户姓名：

联系电话：

地　址：

QUICK START GUIDE

HJ-ME28A Ear Clip Style Bluetooth® Headphone

Product Overview



LED indicator (earphone)
Power on：White and blue lights alternate flashing
Power off：The white light on 2s and then turn off
Pairing is successful：The indicator light goes out
Pairing timed out：The white light on 2s and then turn off
Disconnect the phone：White and blue lights alternate flashing
Low battery：White flashes
LED indicator (charging case)
Charging：The blue light flash, and the blue light is full and turns on when it is full
Discharge：When the charging case charges the earphones, the white light stays on and turns off when it is full
Low battery：White flashes

MFB Operation

Call
Answer/end a call: Double press the MFB button (both left and right earphone can be operated).
Reject the call: When an incoming call comes, press and hold for 2 seconds (both left and right earphone can be operated).

Volume control
Turn down the volume: While music is playing, press the MFB button on your left earphone.
Turn up the volume: While music is playing, press the MFB button on your right earphone.

Music
Play/pause: Double press the MFB button (both left and right earphone can be operated).
Previous song: Connected mobile phone status, left earphone quickly press 3 times.
Next song: Connected mobile phone status, right earphone quickly press 3 times.

Voice Assistant
Connected mobile phone status, long press the MFB button for 3 seconds to wake up voice assistant.(both left and right earphone can be operated).

Wearing
Put the “**HJ-ME28A**” onto your ears and rotate to fit comfortably to get the best wearing and sound quality experience.



Pairing
Open the cover of the charging case ,take out the earphones,the earphones will turn on automatically.For new device connection, turn on the Bluetooth in your device and choose **“HJ-ME28A”** from the Bluetooth list to connect. You will hear system prompts after the earphones are connected to the device.
If the earphones have been connected before, they will connect to the last connected device automatically after being turned on.

Reset
In the power on state, touch the MFB of the earphones 5 times (two earphones at the same time),The earphones will automatically power off, return to the charging case, and perform a reset (this clears the pairing record between the earphones and the phone, but does not reset the left/right earphones pairing). When the earphones are taken out again, they will power on and search for a new pairing.

Product Cleaning
We recommend regularly cleaning the charging contacts of the charging case and the earbuds, as well as their surfaces.

Attention
*Private replacement of batteries without permission is not recommended.
*Batteries [battery packs or battery combinations] should not be exposed to lighting, baking or similar overheating environments.
*The input voltage and current standard ≤ 5V/0.5A when charging the headset charging compartment from an external power source;

The model approval code (CMIIT ID) of the radio transmission equipment of this device has been printed on the product body in silk screen.

JVC is a trademark of JVCKENWOOD Corporation, used by Shenzhen Monster Creative Technology Co., Ltd. under license.

This product is exclusively developed, manufactured, by Shenzhen Monster Smart Internet Co., Ltd. (Shenzhen Monster Creative Technology Co., Ltd.).

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Shenzhen Monster Creative Technology Co., Ltd is under license. Other trademarks and trade names are those of their respective owners.

▲Safety Warnings and Precautions
To ensure your safety and extend the service life of this product, please strictly follow the warnings below:
1. Environmental Warnings
• Do not use this product in extremely high or low temperatures, or in dusty or humid environments.
• Avoid direct sunlight, fire exposure, or any overheating conditions.
• In environments with strong wireless signals or dense crowds (such as airports, stations, exhibitions, etc.), intermittent connection or interference may occur. This is within normal range. Please continue to use the device later or change the usage environment.
2. Operational Safety Warnings
• Do not drop, strike, or subject the product to strong vibrations.
• Do not disassemble or modify the device without authorization to avoid hazards or damage.
• If any abnormal condition occurs, stop using the product immediately and contact your distributor.
3. Battery and Charging Warnings
• When the charging case indicator shows low battery, please recharge in time. If the product is not used for a long period, please recharge it at least once every 30 days.
• Use power adapters that comply with national standards and are LVD-certified.
• The earbuds contain built-in batteries. Do not expose them to high temperatures or flammable environments.
• If the charging port of the earbuds contains foreign objects or has poor contact, gently clean the charging port with a cotton swab dipped in alcohol. Regular cleaning is recommended to ensure proper charging and power-on/off functions.
4. Important Notes
• If there are updates or changes to product functions, please refer to the official website or the sales page for the latest information.
• Please keep this manual for future reference.

封底